

1467820008 Tusk SubZero Plow Mount



TUSK[®]

Safety Instructions

For your safety and the safety of others, we have provided some basic safety instructions. We have also included safety stickers on the plow itself as a reminder. We recommend that you read and understand all safety instructions before operating the plow system. It is not possible to warn you about all potential safety risks when using this plow system. We suggest operating cautiously and using good judgement in addition to reading and understanding the following:

SEVERE INJURY, DEATH, OR EQUIPMENT DAMAGE MAY RESULT IF SAFETY INSTRUCTIONS ARE NOT FOLLOWED.

- Read snowplow instructions, UTV operators manual, and safety decals before operating.
- Wear safety protection as recommended in UTV operators manual.
- When plowing snow into a pile, start backing up before raising the blade.
- Keep bystanders away from plow or UTV while plowing or stationary.
- When blade is not in use, stop UTV engine, lock brakes, and lower blade to the ground.
- Do not exceed 5 MPH with blade installed.
- Operate with extreme caution on slopes, steep grades, and rough terrain.
- Do not allow riders on blade or UTV while moving or stationary.
- Be aware of hidden objects under the snow as they may violently alter the speed and direction of the UTV.
- Do not exceed 5 MPH with plow mount installed even with plow and push tubes removed.
- Remove Plow Mount before resuming normal trail use.

Assembly Instructions:

Thank you for purchasing the *Tusk SubZero Plow System*.

Note: For instructional videos, refer to <https://www.youtube.com/@rmatvmc>

Assembly instructions are not difficult but should be followed precisely and in order.

Two people and proper tools will make the assembly go smoothly.

Assembly: Before you throw any packaging away, make sure you received all of the necessary hardware:

Parts List:

- | | |
|---------------------|-----|
| Plow Mounting Plate | (1) |
| Straight Clamp | (2) |
| M10 x 70mm Hex Bolt | (4) |
| M10 x 30mm Hex Bolt | (2) |
| M10 Washer | (4) |



1467820008 Tusk SubZero Plow Mount



TUSK

Preparation:

Safely support the vehicle so you can access the undercarriage. Installation is much easier with a friend.

Mounting:

1. Remove front bumper plate.
2. Remove front skid plate.
3. Remove lower side bolts from front guard.
4. Position plow mounting plate to align upper holes with the side holes from the front guard. (Fig. 1)
5. Thread two M10 x 30mm bolts loosely into the side holes. (Fig. 1)
6. Place the two straight clamps over the frame on each side of the differential mount. (Fig. 2)
7. Insert four M10 x 70mm bolts through a washer each, through the mounting plate and thread loosely into the straight clamps. (Fig. 3)
8. Go back through and tighten all bolts, alternating between sides on the clamp bolts to keep the clamps parallel to the mounting plate.

