



Tusk Chain Press Tool Instructions

**Note – Always refer to chain installation instructions, as they may vary. This tool is used to install “Clip Type” master links. The master link side plate usually needs to be pressed on in order to install the clip. This tool makes pressing the side link on a simple task.*

1. Line up the chain so both chain ends meet on the rear sprocket. Insert the connecting link from the backside of the chain. Place the press fit link onto the connecting link. Roll the rear wheel forward enough that the connecting link is off the rear sprocket.
2. Take out one of the side bolts from the Chain Press Tool, and loosen the other side bolt as far as possible without removing it. Make sure the center bolt is backed out far enough to allow the center plate and top plate to sit flush against each other. Install the tool over the connecting link making sure the connecting links pins are in the lower and center plate’s grooves. Install the removed side bolt. Tighten the side bolts snugly so the upper and lower plates are square with each other.
3. Tighten the center bolt to push the connecting link’s side plate onto the pins. Press the plate on far enough for the spring clip to be installed properly. **Do not press the side plate on too far causing the chain to bind.**
4. Remove the Chain Press Tool and install the spring clip. Make sure the spring clip is pointing towards the chain’s rotation.

