

Tusk Flexx Bar Handguard Mounts



Congratulations on your purchase of these handguard mounts.

This kit will provide you the option of mounting full wrap-around aluminum handguards to your Fasst Flexx handlebars. Please insure that you received all components and verify all bolts are tight before you ride.

Note: For instructional videos, refer to www.rockymountainatvmc.com/videos.

Assembly: Before you throw any packaging away, make sure you received all the necessary hardware:

Part list

- 2 anodized aluminum mounts.
- 2 stainless steel collars.
- 2 Allen head bolts.
- 2 hex head bolts.
- 2 washers.

Installation steps:

1. Start by locating the left and right aluminum mounts. (There is a laser etched "L" or "R" for the left or right). Insert the stainless steel collars into the back of the mounts. (Apply a small amount of grease to the collars before installation, this will improve the pivoting motion of the mounts.
2. Take the 2 Allen head bolts and place the 2 washers on the bolts. (Apply a little anti-seize lubricant to the bolt's threads). Insert the bolts through the front of the mount and thread into the front of the Fasst Flexx handlebars, these can be tightened at this point in the installation.
3. You can now install your wrap-around handguards and using the 2 hex head bolts, you can bolt the end of your handguards to the Flexx Bar Mounts. Enjoy!

Note: Check bolts after every few rides and after any crash to insure bolts are tight.

