



TUSK Modular UTV Pack Mounting Instructions

Note: This procedure will vary from one UTV to another. If other mounting hooks already exist in the bed, it is recommended they are used.

Step 1: Clean the bed of your UTV.

Step 2: Put Tusk UTV pack in the bed, center and position how you wish. Adjust the side cooler packs up or down to fit on the wheel wells.



Step 3: Decide on the best location for the bed mounts (there are a couple options on the front and rear of the main bag).

Step 4: With the small D-Ring mounted to the bag hook, position D-ring so that the pack will be snug and centered with the bed. Once you have positioned it, mark the bottom of the UTV bed in the mounting hole of the D-ring.



Step 5: Once all 4 D-ring mount locations have been marked, remove the pack from the bed. In preparation of drilling, look at the underside of the bed and make sure the drilling and D-ring mounting won't interfere with anything.

Step 6: Drill a hole in the bed on your marked locations.

Step 7: Using the 6mm bolt, washer, and nylock nut, secure the D-ring to the bed. Once you have completed all four mounting points, attach the pack.



Note: On the Can Am Commander, it is easiest to mount the D-rings to the removable Bed cover.