


# NECK BRACES SIZING

cm/inch	66 - 70 25.5" - 28"	70 - 74 28" - 29.5"	74 - 78 29.5" - 31"	78 - 82 31" - 32.5"	82 - 86 32.5" - 34"	86 - 90 34" - 35.5"	90 - 94 35.5" - 37"	94 - 98 37" - 38.5"	98 - 102 38.5" - 40"	102 - 106 40" - 41.5"	106 - 110 41.5" - 43"	110 - 114 43" - 45"	114 - 118 45" - 46.5"	118 - 122 46.5" - 48"	122 - 126 48" - 49.5"	126 - 130 49.5" - 51"		
 <b>AVERAGE CHEST</b>				DBX/GPX 4.5 S/M														
								DBX/GPX 4.5 L/XL										
		DBX/GPX 5.5 Jr																
					DBX/GPX 5.5 S/M													
									DBX/GPX 5.5 L/XL									
				DBX/GPX S/M														
								DBX/GPX L/XL										
					DBX/GPX 6.5 S/M													
									DBX/GPX 6.5 L/XL									
				STX S/M														
								STX L/XL										
													STX XXL					
					STX RR CUSTOM FIT WITH RACING EQUIPMENT													

*please use:*



Chest  
circumference  
right below  
the arms

- To determine the correct size: locate the correct brace based on your chest circumference indicated along the top line
- Chart applies to riders with average proportions. If you have a flat / barrel shaped chest you can refer to the complete sizing chart at [www.leatt.com](http://www.leatt.com).
- Chest measurement: measure just under the arms, across the fullest part of the chest, around the shoulder blades holding the tape firm and level
- If the chest measurement is on the borderline between two sizes, go to the higher size for a better fit.
- The chart is based on the fact that the brace will be worn directly on the body. If the brace will be worn with other protective gear this size change must be taken into consideration.