

Tusk ATV/UTV Wheels



Thanks for your purchase of the Tusk ATV/UTV Wheel. Please take note of the information and instructions below to get the most out of your Tusk Product. If you don't feel comfortable with this install, please have a qualified mechanic install for you.

For instructional videos, refer to www.rockymountainatvmc.com/videos

Attention: Use proper ATV tire mounting practice and equipment.

When mounting Tusk wheels to your ATV or UTV, always use tapered lug nuts and refer to your service manual for torque specs and stud maintenance. Failure to do so could result in wheel damage and void all warranty.

Care:

To prevent pitting or corrosion of your wheels please follow the proper cleaning solution. Dirt, mud, and dust can corrode the wheel if not cleaned after each use.

Clean wheels with a mild soap, sponge, and clean water. When drying use a non-abrasive towel. Make sure to dry after cleaning. Water and soap buildup can cause spotting of your wheels and in time will dull the finish. Do not use abrasive chemicals or materials on the wheels. Periodic waxing will protect the wheels finish from the elements. Hand wax only as machines can cause more friction and hurt the finish of the wheels.

Limited Warranty

Tusk wheels carry a limited warranty that protects your wheels in a structural failure under normal use applications. Tusk holds a 1-year warranty against manufacture defects in the finish of the wheels. This warranty is only intended for the original retail purchaser.

Tusk will not warranty the following cases:

- Does not cover weather corrosion, chemical corrosion, improper cleaning/maintenance, or neglected damages. Refer above to care maintenance on wheels.
- Damage to the wheel due to failure to follow complete instructions
- Damage or structural failure in a racing/competition environment.
- Damage occurring in an accident or road conditions.
- Tusk is not responsible for damage caused by improper assembly/installation.