

## **Tusk UTV Rear Window**

- Unroll window and position with the window facing towards the top of the roll cage. The Velcro above the window should face outward.
- 2. Loosely attach the window to the roll cage using the 3 straps on each side. After both sides have been attached, tighten the straps and make any necessary adjustments.
- 3. Lift up the bed and clean the edge of the rear back guard located between the bed and the cab. Using the provided Velcro hook, attach it to the upper edge of the back guard where it lines up to the Velcro loop on the Tusk window. Some trimming of the Velcro strips may be necessary depending on which model of UTV you own. Attaching the bottom of the window to the machine will help prevent dust from coming up into the cab.
- 4. Once this has been attached, secure the bottom of the window to the Velcro strip and make any necessary adjustments.

<u>Note</u>: If the rear window is being used in conjunction with the Tusk Rhino Roof, make sure the Velcro on top of the window aligns with the Velcro on the roof.

<u>Warning</u>: For safety purposes and to ensure the longevity of the Tusk rear window, it is recommended it is removed during transportation.







