



Tusk Compact Control Switch

The Tusk Compact Control Switch can be used on a variety of machines. The plastic connector on the wires plugs directly into the Tusk Enduro Lighting Kit's wiring harness. If you are using the control switch for other applications, the connector may be removed; however, pay close attention to the color of the wires.

Headlight (3 individual wires)

- Black – Headlight main
- White – Low beam
- Dark blue – High beam

Wires from main connector

- Dark blue – Turn signal main
- Light blue – Right turn signal
- Orange – Left turn signal
- Light green – Horn (in)
- Black – Horn (out)



Mounting Instructions

1. Remove the Phillips head bolts from the back side of the control housing.
2. Install the supplied rubber strips to the outer edges of the rear half of the control housing.



3. Install the control switch to the handlebar in a suitable position. The switch is designed to work on a 7/8" handlebar surface.
4. Secure wires to the handlebar using zip ties. Make sure the wires do not interfere with any other controls.
5. Attach the wires as required. (max voltage = 14; Max amperage = 7A)

