



Tusk Rhino Roof Instructions

1. Loosely position roof over the top of the roll cage with the longest straps positioned towards the front of the roll cage.
2. Remove the clips from the front straps of the roof. Using the stock allen head bolts on the roll cage, attach the clips to the roll cage by fastening the bolts through the holes in the webbing.
3. Loop the rear straps through the rear supports of the roll cage so they are secured through the supports.
4. Attach the clips in the front and rear to roof. Go around to the attachment points of the roof, tightening down the straps. Make sure the roof fits snugly on the roll cage.
5. Secure the inside Velcro straps on the underside of the roof to the roll bar.



Warning: For safety purposes and to ensure the longevity of the Tusk Roof, it is recommended the roof is removed during transportation.